

TruVent®

INSTALLATION POUR LONGEUR DE PLUS DE 3 PIEDS

Pré percer tous les trous

1. Pour le meilleur résultat: Dans l'encavure de réception ou que la visse est non-apparente, insérer une visse No.6 5/8" au 16" a 24". Pour les longueurs qui excède 3 pieds: Dans l'encavure à côté de celle d'insertion, insérer une visse No.6 5/8" au 24" à 32". (Cette visse sera apparente dans l'encavure).
2. Pour éviter la "stress" sur les panneaux- **Pré percer chaque endroit vissé** un peu plus large que la visse. Ne pas trop serré la visse pour permettre l'expansion et rétraction.
3. Pour une coupe idéale utiliser une lame de scie pour couper le métal.

TruVent®

INSTALLATION FOR LENGHTS THAT EXCEED 3 FT

Pre-drill all holes before inserting screws

1. For best result : Insert a No.6 5/8" screw every 16" to 24" in the receiving groove where the screw will be non-apparent. Then, insert a No.6 5/8" every 24" to 32" into the groove next to the inserting panel. (This screw will be apparent in the groove).
2. To avoid "stress" on the panel : **Pre-drill every holes** slightly larger than the screw. Do not overtighten, allowing for expansion/retraction.
3. For ideal cut, use a saw blade for metal.